



# 00 SCP Launcher


How to Open Toolbars Use **SCP(S) > Launcher** to open the SCP launcher.





**1** Close SCP launcher


**2** Drag to place any position


**3**  Crane tool

**4**  Vehicle tool · Construction machine

**5**  Temporary enclosure · Gate tool

**6**  Scaffold Framework tool


**7**  Temporary Shoring tool


**8**  Strut and Wale tool

**9**  Ground Anchor tool

**10**  Road Deck tool


**11**  Guardrail tool

**12**  Drilling shape generation tool

**13**  Volume display tool

**14**  Coordinate display tool

**15**  Object moving tool

**16**  Object display configuration tool