



# 14 Object display settings

How to call tools From the SCP launcher → Click the "Object display settings" icon




Select the object display setting icon


How to use You can change the display setting of placed all of the objects

1	Guideline	ON	OFF	SCP
2	Colored in plan view	ON	OFF	
3	Object pen use	ON	OFF	

1 Set the ON / OFF of the guide lines of the SCP object



2 Set the ON / OFF of the coloring in the plan view of the SCP object



3 Set the object pen of ON / OFF of the SCP object

